

EMERGENCY LED BEACON 2PK

INSTRUCTIONS

MODEL NO.: 10050001

INCLUDES

- 2 x Emergency LED Beacon
- 2 x 1200mAh Rechargeable battery
- 6 x AAA battery
- 2 x USB-C cable



OPERATION

- To turn unit ON: Press the power button.
To change mode: Press the power button gently until desired flash pattern is found.
To turn unit OFF: Press the power button.

LIGHT MODES

Mode 1	6 LED flashlight	Mode 6	Alternate
Mode 2	Double blink	Mode 7	SOS rescue (morse code)
Mode 3	Double pulse	Mode 8	Solid on (High)
Mode 4	Single blink	Mode 9	Solid on (Low)
Mode 5	Rotate	Mode 10	Red 2 LED flashlight

BATTERY REPLACEMENT

1. Lift the hanging hooks on the back of unit and turn counter clockwise to loosen and remove the battery cover.
2. Replace the 3 x AAA batteries or rechargeable battery pack in the proper orientation shown on the battery holder.
3. Replace the battery cover and turn clockwise to tighten using the hanging hooks to ensure a tight seal.

CHARGING

1. Remove the rechargeable battery pack from the battery holder.
2. Connect the battery pack to a USB power source using the supplied USB cable.
3. The charging indicator will illuminate red while charging.
4. When the battery is fully charged, the indicator will turn green.
5. Reinstall the rechargeable battery pack into the battery holder before use.



Use USB cable to charge

IMPORTANT INFORMATION

- Do not cover lens while in use.
- Do not use near flammable liquids, gases, or in high temperatures.
- When the light begins to dim, stop use and charge immediately.
- Do not charge the unit for more than 24 consecutive hours with AC adapter and 8 hours with DC adapter.
- Store in a clean, dry environment.
- Keep out of reach of children.
- Never stare directly into the light.
- Strong impacts may cause damage to the unit, handle with care.



WARNING!

- Do not disassemble product.
- Do not charge the battery if the product / battery is cracked or damaged.
- Do not short terminals, crush, heat above 60°C, throw into a fire, or incinerate. Please recycle.

SPECIFICATIONS

Model	10050001	Runtime	Approx. 1.5-114 hours (depending on mode & battery type used)
Dimensions	130L x 130W x 40Hmm	Battery	1200mAh lithium battery / 3 x AAA batteries
Weight	150g each	Charging Port	USB-C
LED Configuration	6 top LEDs, 12 base LEDs	Charging Time	Approx. 2 hours
Brightness	Up to 150 lumens	Waterproof rating	IPX5

RUNTIME

Mode	AAA Batteries	Rechargeable Battery
Mode 1 (6 LED flashlight)	18hrs	5.5hrs
Mode 2 (Double blink)	22hrs	14hrs
Mode 3 (Double pulse)	16hrs	13hrs
Mode 4 (Single blink)	114hrs	58hrs
Mode 5 (Rotate)	14hrs	10hrs
Mode 6 (Alternate)	3.5hrs	3hrs
Mode 7 (SOS rescue morse code)	4hrs	3.5hrs
Mode 8 (Solid on High)	2hrs	1.5hrs
Mode 9 (Solid on Low)	3.5hrs	3hrs
Mode 10 (Red 2 LED flashlight)	17hrs	10hrs

