



OWNERS MANUAL

FAST FRAME TENT 4 PERSON

10001502

BEFORE YOU BEGIN

- This tent requires a minimum of two people to set up
- Read all the instructions before setting up your tent
- Check parts list to ensure you have full contents
- Find a flat area for your tent, free from rocks, potholes and branches
- Ensure that you use all pegs, ropes and additional poles only as instructed
- If conditions are windy, arrange tent to have narrowest side of tent facing into the wind
- Keep away from open flames, DO NOT USE stoves or burning appliances inside the tent

STORAGE

- To maximise the life of your tent, always ensure it is clean of dirt and debris
- Never store if wet or damp. Consider airing your tent at home after your trip and allow to completely dry before storing between trips
- Continued exposure to sunlight can degrade the polyesters used to make tents. Always store your tent in its storage bag, away from direct light in a cool, dry space



DuraPlus vestibule pole x 1:



Steel awning pole x 2:



CONTENTS

- Inner tent x 1
- Rain fly x 1
- DuraPlus vestibule pole x 1
- Awning poles x 2
- Pegs x 21
- Bags x 3
- Guy ropes x 2

OZtrail® is a registered trademark of
Adventure Trading Australia Pty Ltd

Designed by:
Adventure Trading Australia Pty Ltd
71 Charles Ulm Place,
Eagle Farm, QLD 4009
AUSTRALIA



SEE OTHER SIDE FOR PITCHING INSTRUCTIONS


Made in Bangladesh

OWNERS MANUAL

FAST FRAME TENT 4 PERSON


10001502

STEP 1: LAYOUT THE INNER TENT



- Unfold the inner tent and outstretch over a flat, clear area
- Arrange the door so it is facing your desired area for entry & exit
- Fold leg poles away from the center of the tent, so the roof framing stands up

STEP 2: ERECT THE INNER TENT FRAME



- Locate the lower leg section of the frame
- Raise to near vertical orientation
- Extend the leg section until the locking button clicks into the locked position, repeat on other legs

STEP 3: PUT ON THE RAIN FLY



- Place rain fly over the inner tent so red webbing on the rain fly faces the rear of the tent
- Place vestibule pole through pole sleeve located above the door on the underside of rain fly
- Insert ends of pole into eyelets on inner tent webbing clips

STEP 4: SECURE RAIN FLY TO INNER TENT



- Secure rain fly to tent with hook and loop tabs located on underside of rain fly
- Connect the rain fly to the tent using the red and grey buckles on the corners

STEP 5: SECURE TENT TO GROUND



- Pull tent out tight from one corner, peg into the ground then repeat on other corners
- Peg out the tent with all guy ropes around the perimeter
- Assemble awning using door panel, awning poles, ropes and pegs

CHANGING WEATHER CONDITIONS



- In light winds and rainy conditions, awnings must be dismantled, and doors must be closed, and guy ropes must be checked to ensure they're tight
- If weather conditions get worse, the tent needs to be packed away to avoid any damage or injury

PACK UP:

TO TAKE DOWN THE TENT, REVERSE THE PREVIOUS STEPS