



OWNERS MANUAL

GAZEBO PORTICO DELUXE 3.0M

10001510

BEFORE YOU BEGIN

- This tent requires a minimum of two people to set up
- Read all the instructions before setting up your tent
- Check parts list to ensure you have full contents
- Find a flat area for your tent, free from rocks, potholes and branches
- Ensure that you use all pegs, ropes and additional poles only as instructed
- If conditions are windy, arrange tent to have narrowest side of tent facing into the wind
- Keep away from open flames, DO NOT USE stoves or burning appliances inside the tent

STORAGE

- To maximise the life of your tent, always ensure it is clean of dirt and debris
- Never store if wet or damp. Consider airing your tent at home after your trip and allow to completely dry before storing between trips
- Continued exposure to sunlight can degrade the polyesters used to make tents. Always store your tent in its storage bag, away from direct light in a cool, dry space



*Gazebo not included

CONTENTS

- Portico tent x 1
- Steel poles x 2
- Fibreglass pole x 1
- Pegs x 12

OZtrail® is a registered trademark of
Adventure Trading Australia Pty Ltd

Designed by:
Adventure Trading Australia Pty Ltd
71 Charles Ulm Place,
Eagle Farm, QLD 4009
AUSTRALIA

Made in Bangladesh




SEE OTHER SIDE FOR PITCHING INSTRUCTIONS

OWNERS MANUAL

GAZEBO PORTICO DELUXE 3.0M

10001510

STEP 1: LAYOUT THE PORTICO



- Assemble your gazebo as per manufacturers instructions
- Unpack your portico and check that all parts are there
- Lay your portico flat on the ground

STEP 2: ATTACH PORTICO ONTO GAZEBO



- Attach three clips on the roof straps onto the gazebo roof frame struts
- Attach the two hook and loop tabs on the top of the tent onto the gazebo canopy
- Attach hook and loop tabs on the side of the portico onto the gazebo legs
- Note: Depending on the model and brand of your gazebo, you may need to adjust the height settings on the gazebo legs and tension the straps to ensure the floor of the portico reaches ground level

STEP 3: ASSEMBLE PORTICO



- Peg out the portico to ensure sufficient tension on front and sides
- Insert the fibreglass pole through the sleeve and into the smaller diameter hole on the 2 way connector, then insert onto the other sides connector
- Insert steel upright pole into the larger diameter hole on the 2 way connector then the bottom of that pole into the ring and pin located on the ground, repeat on other side
- Attach bottom of portico onto gazebo leg with the metal hook with stretchy webbing

STEP 4: SECURE TENT TO GROUND



- Adjust the peg points where needed to ensure the shelter is tensioned correctly
- Peg out the guy ropes to ensure the shelter is set up fully and correctly

STEP 5: CHANGING WEATHER CONDITIONS



- In light winds and rainy conditions, doors and windows must be closed, and guy ropes must be checked to ensure they're tight
- If weather conditions get worse, the tent needs to be packed away to avoid any damage or injury

STEP 6: SECURE THE PORTICO TO GROUND



- Adjust the peg out points, where needed, to ensure correct tension throughout the portico
- Peg out all the guy ropes

PACK UP:

TO TAKE DOWN THE TENT, REVERSE THE PREVIOUS STEPS