COMPANIONS° AQUAHEAT™NXT DELUXE ENSUITE


10001865

ASSEMBLY & CARE INSTRUCTIONS

Companion® advises to assemble your ensuite before use to ensure all parts are present and to become familiar with the assembly of your ensuite. Choose a flat level area with no objects that could damage the floor.


HELPFUL HINT: Be careful not to twist or force the frame assembly when unfolding the ensuite. It is not necessary at any stage of the ensuite assembly to apply more than a small force on the frame. If a small force is not sufficient to carry out each described step, then realign the frame and try again.


SET UP






Find a level area to pitch the ensuite. Remove from bag, lay out on ground with door facing the correct direction. Peg down the ensuite on all four peg points.





Before extending upright legs into position. Ensure legs are facing upright and central hub facing down (refer to figure 3). Next pull up on central hub with mild force to lock into position. Next extend out each upright leg until locking pin locks into place (refer to figure 4).





To install rain fly: Place rain fly over top of frame system Attach via four loops onto each corner leg Secure guy ropes to ground with pegs

To assemble Aquaheat NXT system gusset:

Install fibreglass pole through sleeve and into metal ring and pins on base

Peg the base out tightly

To assemble toilet room on right hand side


Install steel upright poles into plastic connector at top and then into metal ring and pin on base Install fibreglass pole through sleeve at top of room and into plastic connectors each side Peg the base out tightly

In severe conditions the shelter should be dismantled. **PACK DOWN:** To pack down this shelter, reverse the above steps.


LIGHTING SYSTEM




Add 4 D batteries to battery pack (batteries not included)



Put battery pack inside storage



Plug battery pack into lighting connector



Press button on switch to control lighting system

NOTE: light can be run off an alternative 5V power sources such as a power bank, plug directly into lighting connector to power

IMPORTANT

Thank you for purchasing a quality Companion® product, if you have any questions your Companion dealer will be happy to help you or contact us at www.companionoutdoor.com

- This product is designed as a portable and temporary shelter and is not for permanent use.
- Avoid continuous exposure to sunlight as this will eventually cause the fly material to weaken, fading is an early warning sign of this process.
- Before storing the shelter ensure the it is clean and completely dry. Never store a damp or wet shelter.

TO PREVENT INJURY CAUSED BY FIRE



- The fabric may burn if it comes into contact with a flame source
- Do not pitch the shelter near a camp fire or any other flame source
- Do not use candles, matches or any other flame source in or near the shelter (this includes stoves, cooking equipment, lighting and heating appliances)
- Only use recommended water repellent compounds on the shelter
- Do not spray shelter fabrics with insecticides

TO PREVENT INJURY CAUSED BY ELECTRICITY

- Always exercise care when using electricity and electric lighting in and near shelter
- Only use 5 volt lighting

TO PREVENT INJURY CAUSED BY YOUR CAMPING ENVIRONMENT



Do not pitch your shelter on an area that could get flooded



 Do not pitch your shelter near cliffs in case of collapse or rock fall





 Do not leave your shelter erected in strong winds - collapse the shelter onto the ground and seek refuge in your vehicle



 Do not pitch your shelter under trees with dead branches or under trees known to drop branches

CARE INSTRUCTIONS: Wipe down all metal surfaces with fresh water after use. To remove marks, use a soft brush or sponge with fresh water and mild detergent only and rinse with fresh clean water. Allow to dry thoroughly. Never pack away damp, dirty or wet. After beach use or wet conditions treat all zips and metal components with silicon spray.













WARRANTY - For details see www.companionoutdoor.com/warranty

Designed by:

Adventure Trading Australia Pty Ltd
71 Charles Ulm Place,
Eagle Farm, QLD 4009

AUSTRALIA

