

ROAM TAP



INSTRUCTION MANUAL

Model No. 10001965

ROAM TAP | OWNERS MANUAL companiong

IMPORTANT

Please read this instruction manual carefully before operating the unit.

SAFETY INFORMATION

- This unit is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge.
- Children must be supervised at all times when around this unit.
- Do not alter or dissemble the unit.
- To be repaired by qualified persons only contact Customer Service on 1300 362 921.
- ONLY use this unit to pump clean fresh water.
- DO NOT use this unit to pump alcohol or other corrosive liquids such as oil or water over 55°C.
- D0 not immerse the unit in water.

UNDERSTANDING THE APPLIANCE



Roam Tap contains a 3.7V lithium-ion battery and includes a USB charging cable.

Step 1. Plug the charging cable into the USB-C outlet.

outlet on a computer, wall adapter (not included), etc.

NOTE: Charging while using a USB wall adapter will be faster than a computer

Step 4. Once it reaches 100%, the POWER INDICATOR will be solid. Remove the USB

SETTING UP

companiong

Step 2. Attach the hose to the tap.

Step 2. Plug the USB cord into any USB

cord and store.

NOTE: Always use the supplied cable for charging. Ensure that the unit is fully charged every three months to protect the life of the battery. ROAM TAP | OWNERS MANUAL companiong

Step 1. Attach the base to the tap.

Step 3. Place the tap on a flat, level, stable


NOTE: Ensure the hose passes through the gap in the base.

Step 4. Place the hose in a container filled with clean fresh water.

Step 3. While charging, the POWER INDICATOR flashes.

ROAM TAP | OWNERS MANUAL

OPERATION



Step 1. Press and hold for 3 seconds. It will show **ON** to enter standby mode.

Step 2. Press again to open the tap spout.

Step 3. Choose the required flow setting - pre-set or continuous.

- PRE-SET FLOW SETTINGS: Press and cycle through to select either 200ml,
- CONTINUOUS FLOW: Press to start and press again to stop flow. Continuous flow will automatically stop after 3 minutes.

Step 4. Press and hold for 3 seconds. It will show **OFF** and the unit will power off.

NOTE: After 1 minute of no use, the tap spout will automatically close.

companiong ROAM TAP | OWNERS MANUA

- **Step 1.** Ensure unit is switched off before cleaning
- Step 2. Clean exterior of the unit with a damp cloth only.

NOTE: It is recommended that the hose be replaced every 6 months or depending on frequency

- **Step 3.** To clean the hose, boil for a few minutes. It is recommended to do this every two months or depending on frequency of use.
- **Step 4.** Ensure the unit is completely dry before storing.

NOTE: DO NOT use any abrasive cleaners, harsh chemicals or abrasive cleaning tools.

MAINTENANCE

For further information or assistance please contact customer service on 1300 362 921 or email: info@adventureoperations.com

SPECIFICATIONS

rait Nu.	10001303
Dimensions (open)	14.8L x 7.4W x 16H (cm)
Dimensions (closed)	7.4L x 7.4W x 16H (cm)
Weight	260g
Flow Rate	1300ml / minute
Hose Length	1.5m
Hose Material	BPA free silicone
Runtime	Up to 45 minutes
Charge time	4hrs
Battery	1200mAh lithium rechargeable
Pack Contents	1 x Roam Tap
	1 x Tap base
	1 x 150cm hose
	1 x Hose attachment
	1 x USB charging cable
	1 x Instruction manual
	1 x Storage bag

companion

WARRANTY POLICY

ROAM TAP | OWNERS MANUAL

- 1. Products distributed by Adventure Operations Australia Pty Ltd and any of our subsidiaries come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if products fail to be of acceptable quality and the failure does not amount to a major failure.
- 2. In addition, we warrant that this product will be free from defects in materials and workmanship under normal use as described in the published product documentation for 1 year from the date of original purchase (Limited Warranty). This Limited Warranty is only valid and enforceable in Australia and will apply only if you have purchased the product from us or our authorised resellers.
- 3. To the extent permitted by the Australian Consumer Law and any applicable local law:
- (a) our obligations under this Limited Warranty are limited to the repair, replacement or refund of covered parts that prove defective under normal use during the Limited Warranty and does not extend to any claim for damages that you or any other person may have for any loss (including without limitation consequential damages or loss of profit, freight/shipping or travel costs), or damage howsoever caused whether or not such loss or damage arises as a result of any defect in the product or from the failure or omission on our part to comply with any
- (b) in replacing a defective product under the Limited Warranty, we may, at its discretion, substitute a model of equivalent nature where the exact model is unavailable;
- (c) this Limited Warranty does not apply to damage caused by failure and damage caused by improper use and abuse, fair wear and tear, accidents, misuse (including failure to follow instructions regarding care and maintenance of the product), neglect, disassembly, alterations or external causes such as, but not limited to, water damage, exposure to sharp objects, exposure to excessive force, anomalies in the electrical current supplied to the product (if applicable), and extreme thermal or environmental conditions;
- (d) we may elect, at our discretion and as an alternative to repairing or replacing a defective part to refund the cost of the relevant product upon it being returned to us; and
- (e) this Limited Warranty does not extend to any products acquired for the purposes of re-supply, or for use in a manufacturing, or repair processes.
- This warranty may be claimed by:
- returning the product to its place of purchase, with a detailed proof-of-purchase clearly showing the date and detail of the purchase;
- 5. If you have any questions concerning this warranty policy, you may contact us in writing: Adventure Operations, 71 Charles Ulm Place, Eagle Farm, 4009 QLD, or by email: warranty@adventureoperations.com or visit our website: www.adventureoperations.com

TO THE EXTENT PERMITTED BY LAW. ADVENTURE OPERATIONS AUSTRALIA PTY LTD. ITS SUBSIDIARIES AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY SIMILAR STANDARD IMPOSED BY APPLICABLE LEGISLATION AND ADVENTURE OPERATIONS AUSTRALIA PTY LTD

WARRANTY - For details see www.companionoutdoor.com Companion® is a registered trademark of Adventure Trading Australia Pty Ltd

Designed by: Adventure Trading Australia Pty Ltd 71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA Made in China

