

COMPANION 

TRUSTED SINCE 1941

AEROBREEZE CLIP FAN

20CM FAN



INSTRUCTION MANUAL

Model No. 10051243


IMPORTANT

- Please read this instruction manual carefully before operating the unit.
- To maximise battery life, it is recommended to fully charge the battery every three months.

SAFETY INFORMATION

- This unit is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge.
- Children must be supervised at all times when around this unit.
- Place unit in a well ventilated area when in use or recharging the battery.
- Do not attempt to disassemble or replace the batteries.
- To be repaired by qualified persons only - contact Customer Service on 1300 362 921.
- Do not expose to heat source, rain or submerge in liquid.
- If charging cords become damaged, they must be replaced by a qualified person.
- Do not damage the USB cable, forcefully bend it, pull it, twist it, or use it if frayed or broken.
- Do not use the USB cable if dust has collected or the Type-C connection is loose.
- Do not use with anything other than the dedicated USB cable.
- Do not use near fire or in high-temperature areas.
- If the unit is damaged, stop use immediately and contact Customer Service on 1300 362 921.
- Ensure the cable is fully inserted and not loose.
- Use only the included USB cable for charging.
- This product is for household use only. Do not use for commercial purposes.
- Do not use in places where it may come in contact with water and avoid exposure to rain.
- Do not use if the product is cracked, deformed, or damaged.
- Do not bring face or hair close to the fan outlet or air intake.
- Do not use near materials that easily get sucked in (e.g. curtains, thin cloth, etc).
- Do not drop or subject the unit to strong impact.
- When unplugging the USB cable, always hold the connector - do not pull on the cord.
- Use and store the product in a location with temperature between -10°C and 40°C.

UNDERSTANDING THE APPLIANCE



TO CHARGE

Step 1. Connect the USB cable (included) to the fan's Type-C port, and the other end to a USB port on an AC adapter (not included) or a power source.

Step 2. The battery level indicator light will flash during charging.

Step 3. Once completely charged, the light will stay on.



NOTE: Fan will charge and operate at the same time when using a 2A device. If using a 1A or less device the fan will not operate while charging. Fan needs to be turned off to fully charge.

The fan can also be charged via micro USB (cable not included).

NOTE: To fast charge the fan, a 5V/2A adapter needs to be used. If a 2A device is not used, then charging time will be longer than stated.

FAN OPERATION

Step 1. Press the **POWER** button to turn the fan on.

Step 2. Press the **POWER** button repeatedly to cycle through the four air flow speed settings. The fan speed will increase with each press of the **POWER** button.

- Press 1 (1 light) - Low
- Press 2 (2 lights) - Medium
- Press 3 (3 lights) - High
- Press 4 (3 lights) - Energy Saving

Step 3. Press the **POWER** button until all fan speed indicator lights turn off. The fan will stop once all indicator lights are off.



CLEANING INSTRUCTIONS

Step 1. Ensure unit is switched off and disconnected from a power source before cleaning.

Step 2. Clean with a dry cloth only. The fan is not waterproof.

Step 3. DO NOT use any abrasive cleaners or harsh chemicals.

MAINTENANCE

For further information or assistance please contact customer service on 1300 362 921 or email: info@adventureoperations.com

TROUBLESHOOTING

ISSUE	CAUSE	SOLUTION
Fan does not turn on	Battery is low or not charged	Charge the unit with the included USB cable
Blades are spinning, but no wind	Dust or debris has accumulated around the fan or motor	Clean the fan thoroughly
Fan stops during use	Battery is drained	Recharge the battery fully
Fan won't run while charging	Battery is too low	Wait about 30 seconds after connecting the power, then try turning it on
Unusual noise during operation	Debris is caught in the fan	Turn off the unit and remove the debris safely
Fan slows down while operating	Low battery - the fan automatically slows down to protect the unit when the battery is low	Fully charge the fan

SPECIFICATIONS

Part No.	10051243
Size	20cm
Dimensions	21.8L x 25.6W x 8D (cm)
Weight	600g
Runtime	24hrs (low) / 12hrs (medium) / 6hrs (high) / 12hrs (energy saving)
Battery	2 x 5000mAh lithium battery
Input	5V 2A
Charge Time	Approx. 5 hrs (based on 2A)
Material	ABS Plastic
Operating Temperature	-10°C to 40°C
Pack Contents	1 x Aerobreeze Clip Fan
	1 x USB Charging cable
	1 x Instruction Manual

WARRANTY POLICY

LIMITED WARRANTY AGAINST DEFECTS

1. This Limited Warranty is provided by Adventure Operations Australia Pty Ltd ABN [43 622 679 887] trading as Companion in our capacity as supplier and manufacturer of the Products.

Our contact details are:

Address: 71 Charles Ulm Place, Eagle Farm, 4009 QLD.

Phone number: 07 3193 1110

Email address: warranty@adventureoperations.com

OUR LIMITED WARRANTY

2. This Limited Warranty applies in addition to any other express warranty or warranties against defects we may supply from time to time for specific Products. If the individual packaging, accompanying product information or labelling of a Product specifies a different warranty period from the 12 month warranty period provided in this Limited Warranty, the packaging Warranty Period will apply instead but on the same terms as this Limited Warranty.

The warranty period for this product is 1 year.

3. Moving forward, in this Limited Warranty, Warranty Period means:

- a) for all Companion Products, 12 months from the date of original purchase of the relevant Companion Product; or
- b) another time period set out in the individual packaging, product information, labelling, or accompanying a specific Companion Product.

4. Under this Limited Warranty, we warrant that products distributed by Adventure Operations Australia Pty Ltd and any of our subsidiaries (Products) will be free from defects in materials and workmanship under normal use (as described in the published product documentation accompanying or applicable to the relevant product) for the relevant Warranty Period (Limited Warranty).

5. If a defect in materials or workmanship becomes apparent under this Limited Warranty within the Warranty Period described above, subject to any additional rights you have under the Australian Consumer Law or any applicable local law, we agree to replace or refund covered Product parts that prove defective through normal use during the Warranty Period. We may alternatively agree to repair certain Products through our qualified agents, where such facilities are available. Without limiting any rights you have under the Consumer Law, the following conditions also apply to the Limited Warranty:

- a) in replacing a defective product under the Limited Warranty, we may, at our discretion, substitute the product with a product model of equivalent nature where the exact model of the defective product is unavailable;
- b) we may elect, at our discretion and as an alternative to repairing or replacing a defective part, to refund the cost of the relevant product upon it being returned to us or one of our authorised resellers;

- c) this Limited Warranty does not extend or apply to any claim you or any other person may have for damage for any loss (including without limitation consequential damages or loss of profit, freight/shipping or travel costs), or otherwise damage howsoever caused whether or not such loss or damage arises as a result of any defect in the product or from the failure or omission on our part to comply with any obligation at law relating to the defect;
- d) this Limited Warranty does not apply to damage caused by your failure and damage caused by improper use and abuse, fair wear and tear, accidents, misuse (including failure to follow instructions regarding care and maintenance of the product), neglect, disassembly, alterations or external causes such as, but not limited to, water damage, exposure to sharp objects, exposure to excessive force, anomalies in the electrical current supplied to the product (if applicable), and extreme thermal or environmental conditions; and
- e) this Limited Warranty does not extend to any Products acquired for the purposes of re-supply, or for use in a manufacturing, or repair processes.

REPAIR FACILITIES AND SPARE PARTS

- 6. Please note that we have very limited repair facilities for our Products. This means that subject to any limited repair facilities offered through authorised repair agents, we are not able to repair broken or damaged Products that are broken or damaged by you or are defective. For defective Products, this Limited Warranty and your rights under the Australian Consumer Law will apply and in most cases the remedy will be limited to a refund or replacement.
- 7. Companion carries spare parts for many, but not all, of our Products. A comprehensive catalogue of our spare parts can be found at: Camping Gear Spare Parts. This means that where a Product is broken or damaged by you, we may not be able to provide you with a spare part for that Product. Where a Product is defective, you will be entitled to your rights under this Limited Warranty and the Australian Consumer Law, and in most cases the remedy will be limited to a refund or replacement.

HOW TO CLAIM THE LIMITED WARRANTY

- 8. This Limited Warranty is only valid and enforceable in Australia or New Zealand and will apply only if you have purchased the Product from us directly or from one of our authorised resellers.
- 9. This Limited Warranty may be claimed by you if a defect becomes apparent in the Product within the Warranty Period.
- 10. To claim this Limited Warranty you must do either of the following:
 - a) return the defective product to its place of purchase within the Product's Warranty Period, with a detailed proof-of-purchase clearly showing the date and detail of the purchase;
 - b) make the warranty claim directly with us by returning the defective Product to our address at Adventure Operations, 71 Charles Ulm Place, Eagle Farm, 4009 QLD accompanied by a detailed proof-of-purchase clearly showing the date and detail of the purchase;

c) make the warranty claim directly with us by emailing us at **warranty@adventureoperations.com** accompanied by a detailed proof-of-purchase clearly showing the date and detail of the purchase. We may require you to mail us the product or email us photographs of the defect and Product.

11. Where you return the defective Product in-store to the place of purchase, our authorised reseller will inspect the Product and proof-of-purchase to determine if this Limited Warranty has been complied with and can be claimed. They will also determine the remedy available to you under this Limited Warranty.

12. Where you make the warranty claim directly with us, we will inspect the Product (including by inspecting photographs you send to us over email) and the proof-of-purchase to determine if this Limited Warranty has been complied with and can be claimed. We will also determine the remedy available to you under this Limited Warranty.

EXPENSES

13. You must bear the expense of claiming a remedy under this Limited Warranty, including postage and transport costs of returning the product. If we or our authorised reseller determine you are entitled to a remedy under this Limited Warranty, we will reimburse you for any reasonable expenses you have incurred in making the claim, provided you supply us with proof of such expenses.

YOUR RIGHTS UNDER THE CONSUMER LAW

14. Products distributed by Adventure Operations Australia Pty Ltd and any of our subsidiaries come with guarantees that cannot be excluded under the Australian Consumer Law or the New Zealand Consumer Guarantees Act 1993 (Consumer Law) (as the case may be). You are entitled to a replacement or refund for a major failure (or, where the New Zealand Consumer Guarantees Act 1993 applies, a failure of a 'substantial character') and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if products fail to be of acceptable quality and the failure does not amount to a major failure (or a failure of a substantial character, as the case may be).

CONTACT US

15. If you have any questions concerning this warranty policy, you may contact us in writing: **Adventure Operations, 71 Charles Ulm Place, Eagle Farm, 4009 QLD**, or by email: **warranty@adventureoperations.com** or visit our website: **adventureoperations.com**.

WARRANTY - For details see
www.companionoutdoor.com/warranty

Companion® is a registered trademark of
Adventure Trading Australia Pty Ltd

Designed by: **Adventure Trading Australia Pty Ltd**
71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA
Made in China

