

# LUMOS SPOTLIGHTS 10000466/10000467

### **INCLUDES**

- 1 x Lumos Spotlight (700L or 1200L versions)
- 1 x USB Charging cable
- 1 x Wrist Strap

## **INSTRUCTIONS**

### **CHARGING BATTERIES:**

- 1. Unscrew the back of the spotlight to access the USB charging port
- 2. Check to ensure the Power Lock button is turned off. To check this, press the trigger to turn on the spotlight if there is light this means the power lock is off. (Power lock technology is used to preserve the battery while in storage, it will cut out all power from the battery)
- 3. Use included USB Charging cable to plug spotlight into wall adapter (not included) or computer USB socket
- 4. When charging, battery indicator will flash while charging, the indicator lights will turn solid once the spotlight is fully charged
- 5. Screw the back of the spotlight back on this will ensure the spotlight stays waterproof

  Note: The spotlight will not work while charging

#### OPERATION:

- Turn on: Press the trigger button (if spotlight does not turn on unscrew the back of the spotlight and press the power lock button, this will turn the power lock off and ensure the spotlight can use the battery)
- 2. **Cycle through modes:** Press trigger button once to move through Low, High and SOS modes
- 3. Turn off: Press trigger button once more to turn off
- Power Lock: When you are storing your spotlight, make sure you press the power lock button. This will disconnect the battery and ensure there is limited power loss during storage

(	MODEL	10000466 - 700L		10000467 - 1200L	
	MODE	LOW	HIGH	LOW	HIGH
	LUMENS	400	700	700	1200
ı	RUNTIME	8.5Hr	2Hr	8.2Hr	2.3Hr
l	DISTANCE	150m	350m	350m	500m
(	CHARGE	2.5 Hrs		3 Hrs	

Designed & Imported by: Adventure Trading Australia Pty Ltd 71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA

P: 1300 362 921


www.oztrail.com.au

OZtrail® is a registered

trademark of Adventure

Trading Australia Pty Ltd

Made in China



3 Year Warranty For details see: www.oztrail.com.au/warranty